

# STEP 1. PASSENGER SIDE



\*Locate these 2 holes towards the front of the chassis rail



\* Place the Black spacer to the left hole.



\* Place the Passenger side Recovery point in place like pictured against the 2 holes. This step will 1 person to hold the recovery point with another person to feed through the (**black nut with extended wire**) through the back hole.



Feed the (**black nut with extended wire**) from the back hole through to the left hole so its sitting behind the black spacer.



\*Feed through long stainless bolt through the left hole the **black nut with the extended wire**) WILL capture the long Stainless bolt.



\*Repeat this on the right hole Feed through the 2nd black nut with the wire behind this hole so the bolt can be captured.



**FOR DRIVERS SIDE REPEAT SAME PROCESS WITHOUT THE SPACER IN THE FRONT HOLE**